


**VIEW 6
RECOIL STARTER ASSEMBLY**



DWG ITEM	SURF-JET P/N	DESCRIPTION	QTY	FRT
1-18	1005150	RECOIL STARTER ASSY.	1	
2	1005160	REEL	1	
3	1005170	RATCHET	2	
4	1005180	SPIRAL SPRING	1	
5	1005190	FRICTION SPRING	1	
6	1005200	THRUST WASHER	1	
7	1005210	RETURN SPRING	1	
8	1005220	FRICTION PLATE	1	
9	1005230	BOLT	1	
10	1005240	NUT	1	
11	1005150	BUSHING	1	
12	1005260	STARTER ROPE	1	
13	1002150	ROPE GUIDE	1	
14	1002190	BOLT	2	
15	1002200	SPRING WASHER	2	
16	1005270	THRUST WASHER	1	
17	1002210	STARTER PULLEY	1	
18	1005280	BOLT	1	
19	1005290	BOLT	1	
20	1003230	SPRING WASHER	7	
21	1000050	SPRING WASHER	1	
22	1003240	BOLT	3	
23	1002170	STARTER KNOB	1	
24	1002510	ROPE GUIDE	1	
25	1002180	ROPE STOPPER	1	